



SPECIAL INSTRUCTIONS:

1. Sander is to be used for sanding of wood products only – do not use to sand metal.

2. Electrically powered machine tools must only be used on circuits protected by safety switch or RCD.

3. Loose clothing, jewellery or gloves MUST NOT BE WORN when using moving machinery.

Sequence	Identified hazards	Key processes to be followed	Precautions / PPE required
1. Pre-start checks	Electrical shock	Inspect lead and plug for wear or damage, and ensure power outlet is safe.	Do not use faulty equipment.
	Loose parts	Inspect all screws, bolts and nuts to ensure that all parts are secured.	Tighten or replace loose parts.
	Flying objects	Inspect sanding belt for wear, tears or damage before use.	Replace belt if worn or damaged.
		Check gap between table and belt- should not exceed 1.5mm.	Adjust table if gap too wide.
	Slips and falls	Ensure area around machine is swept to remove dust from floor.	Keep work area clean.
2. Operation	Abrasive belt	Keep hands and fingers clear of sanding belt while sanding – use holding tool or aid	Do not use gloves when sanding.
		when sanding small items (eg, push block or push stick).	Eye protection must be worn.
	Flying objects	Maintain control of item being sanded to prevent unwanted movement.	Ensure that work is placed flat on table
		Allow sanding belt to cut at its own speed – do not force work on to belt.	while sanding.
	Toxic dust	Check material being sanded to assess any risk of toxic dust while sanding.	Dust mask must be worn when sanding
		Exhaust dust collector should be used when toxic dust generated.	MDF or craftwood.
3. Cleaning and	Moving parts	Always ensure that power to machine is switched off before cleaning or	De-energise machine before cleaning or
maintenance		maintaining sander.	maintenance.
	Dust and flying objects	Use brush or tool to remove build up of sanding residue.	Wear eye protection and dust mask
		Use low pressure air to blow dust from cooling vanes of electric motor.	when cleaning sander.
	Replacement of sanding	Release tension on belt after opening cover, remove old belt.	Check belt direction when fitting.
	belt	Ensure that correct belt is selected, slide on to drums, re-tension belt for use.	Use tracking control to centre belt.

PRECAUTIONS:

The following precautions are to be observed in areas where these procedures are carried out.



This information is intended to provide a general guide to the subject matter and must not be viewed as a definitive guide to the law or legal advice. Specialist advice should be sought regarding this subject matter in your jurisdiction and specific circumstances.

Edge Sander was generated by ASSA Pty Ltd on 05 Jun 2023 for use only by Eaglehawk Hire

Uncontrolled when printed or downloaded

© ASSA PTY LTD

SWP0893 Version 4.1

Page 1 of 1